POLARISCOPE



Manual

Dear users:

Glad to choose our polariscope, before using, please read the manual carefully so that to help you operating the polariscope correctly and prolonging its service life .We reserve the rights to change the outlook and packing of our product.

[Notice]

*Don't operate the machine before reading thoroughly and grasping all the instructions and rules. Any violation of the rules stated in the manual may cause accidents such as fire, shock, personal injury etc.

*The light source of polariscope is 220V, while using, please handle with care to avoid the damage.

[INSTRUCTION]

It is used to test and check the inside structure of the lens which suitable for glass, sun glasses, PC lens and crystal lens. It is a necessary for the lens factory or the glass shop.

[Operation]

1.Put the lens on the tested window and then observe the upper window carefully to check the stress situation of the lens.

2. While the process of installing acrylic lens, the stress of screw may be strong and surround that appear some small crack, and you could not know the situation in a short time by your naked eyes. The situation will be heavy, but if you use our machine, you could find out the situation clearly while the process of working.

[Structure]

